



Wall Glazing channel bonded to wall membrane with Fosroc Silaflex NG

Fosroc Silaflex RTV infill

Wall Glazing channel notched to lap to shower tray over floor Glazing channel

Silicon sealant (by others \*)

Membrane interlayer

Shower hob

Bondbreaker tape (prior to tiling)

Support ring set in construction adhesive (e.g. maxbond/nailbond)

8mm toughened Glass Shower Screen

Silicon sealant (by others\*) around perimeter

Selected floor tiles on tile adhesive (by others\*)

Bondbreaker tape (prior to tiling)

Membrane interlayer

55 high hob

DETAIL 4 WALL / FLOOR INTERSECTION  
01 Hob Tray